




36. Lower the hoist.


37. Attach the chain hoist to the engine.




(cont'd)

Engine Removal/Installation (cont'd)


38. Remove the left and right front stopper rubbers and stopper brackets.




39. Remove the rear engine mounting bracket.



40. Remove the engine support nuts. Loosen the mount bolt and pivot the engine side mount out of the way.



41. Remove the transmission mount nuts. Loosen the mount bolt and pivot the transmission side mount out of the way.



42. Raise the chain hoist to remove all slack from the chain.
43. Check that the engine is completely free of vacuum hoses, fuel and coolant hoses, and electric wires.
44. Slowly raise the engine approximately 150 mm (6").
Check once again that all hoses and wires have been disconnected from the engine.
45. Raise the engine all the way and remove it from the car.



46. Install the engine in the reverse order of removal.

NOTE:

After the engine is in place:


- Torque the engine mounting bolts in sequence shown below.

CAUTION: Failure to tighten the bolts in the proper sequence can cause excessive noise and vibration, and reduce bushing life; check that the bushings are not twisted or offset.

- Check that the spring clip on the end of each driveshaft clicks in to place.

CAUTION: Use new spring clips on installation.

- Bleed air from the cooling system at the bleed bolt with the heater valve open.
- Adjust the throttle cable tension.
- Check the clutch pedal free play (M/T).
- Check that the transmission shifts into gear smoothly.




Engine Removal/Installation

(cont'd)

- Adjust the tension of the following drive belts.
Alternator belt (Section 23).
Power steering pump belt (Section 17).
Air conditioner compressor belt (Section 22).
- Clean battery posts and cable terminals with sandpaper, assemble, then apply grease to prevent corrosion.


- Inspect for fuel leakage.
After assembling fuel line parts, turn on the ignition switch (do not operate the starter) so that the fuel pump operates for approximately two seconds and the fuel is pressurized. Repeat this operation two or three times and check whether any fuel leakage has occurred at any point in the fuel line.







Mount and Bracket Bolts/Nuts Torque Value Specifications:


TRANSMISSION MOUNT



REAR MOUNT




ENGINE SIDE
MOUNT




12 x 1.25 mm
65 N·m (6.5 kg-m,
47 lb-ft)

R. FRONT STOPPER



L. FRONT STOPPER



(cont'd)


Engine Removal/Installation

(cont'd)


Mount and Bracket Bolts/Nuts Torque Value Specifications:

REAR MOUNT

D16Z6 (A/T), B16A2 (A/T):




Except D16Z6 (A/T), B16A2 (A/T):





ENGINE SIDE MOUNT

B16A2:




TRANSMISSION MOUNT

4WD:



R. FRONT STOPPER


4WD:



M/T:

L. FRONT STOPPER

CARS NOT EQUIPPED A/C:





Additional Torque Value Specifications:

12 x 1.25 mm
M/T and A/T: 60 N·m (6.0 kg-m, 43 lb-ft)

FRONT
STIFFENER
(A/T only)

(D15Z1, D15B8)

INTAKE MANIFOLD
BRACKET
(D15B7, D16Z6)

ALTERNATOR BRACKET

8 x 1.25 mm
24 N·m (2.4 kg-m, 17 lb-ft)

REAR
STIFFENER
(D16Z6 A/T only)

8 x 1.25 mm
22 N·m (2.2 kg-m,
16 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m, 33 lb-ft)

ENGINE SIDE
MOUNTING BRACKET

EXHAUST MANIFOLD
BRACKET

8 x 1.25 mm
22 N·m (2.2 kg-m,
16 lb-ft)

10 x 1.25 mm
55 N·m (5.5 kg-m, 40 lb-ft)

P/S PUMP BRACKET

A/C COMPRESSOR BRACKET

10 x 1.25 mm
45 N·m (4.5 kg-m, 33 lb-ft)

8 x 1.25 mm
22 N·m (2.2 kg-m,
16 lb-ft)


10 x 1.25 mm
45 N·m (4.5 kg-m, 33 lb-ft)

(cont'd)

Engine Removal/Installation

(cont'd)


**D16A6/7 (DOHC):
INTAKE MANIFOLD
BRACKET**




8 x 1.25 mm
22 N·m (2.2 kg-m,
16 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)

ENGINE HANGER




**ENGINE SIDE MOUNTING
BRACKET**



10 x 1.25 mm
55 N·m (5.5 kg-m,
40 lb-ft)


P/S BRACKET




10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m, 33 lb-ft)

B16A2:



A/C PUMP BRACKET




10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)

P/S BRACKET

HEAT SHIELD



8 x 1.25 mm
22 N·m (2.2 kg-m,
16 lb-ft)

10 x 1.25 mm
45 N·m (4.5 kg-m,
33 lb-ft)