

Systems Description

Electrical Connections [1.6 l]

With CATA

- FUSES**
① ECU (15A)* ④ No.1 (10A)
② No.14 (10A) ⑤ HAZARD (10A)*
③ No.2 (10A) * : In the main fuse box

